

AIR NOZZLES

PART NO.	AIR NOZZLE	PART NO.	AIR NOZZLE	PART NO.	AIR NOZZLE	PART NO.	AIR NOZZLE
46-4002	1/4 inch	46-3027	36SD	46-6082	66SK	46-9500	95P
46-2101	101 TIP	46-3050	36SK	46-6026	67PB	46-6882	96G
46-2190	190 TIP	46-3040	38PM	46-6028	67PD	46-9703	97AP
46-2191	191 TIP	46-2302	302SS	46-6032	68PB	46-9702	97AS
46-2200	200 TIP	46-2390	390SS	46-2013	706 TIP	46-9700	97P
46-2201	201 TIP	46-2391	391SS	46-2020	709SS TIP	46-6083	A68PB Alum 7N
46-2206	206 TIP	46-6000	63P	46-7005	78S	46-1031	AA1
46-21MD-1	21MD-1	46-6002	63PB	46-7006	78SD	46-131	J92P 460 Gun
46-21MD-2	21MD-2	46-6061	63PH-1 (for Adhesives)	46-9050	905P	46-126	J92R 460 GUN
46-21MD-3	21MD-3	46-6079	63PR (for high solids)	46-9000	90P	46-1042	R-6SS
46-2242	242	46-6091	63PW (for high solids)	102-2681	92PC	46-1046	R27SS
46-2244	244	46-6007	64PA	102-2926	91PCSS	54-5346	AA-10
46-2250	250	46-6013	66PD	46-9505	92P	54-4978	AA-4
46-2252	252	46-6014	66PE (anti-fogging)	102-2682	91PC	54-4980	AA-2
46-2262	262	46-6016	66PH (anti-fogging)	102-2924	92PCSS	54-5795-K	AA HVLP F
46-9900	2S	46-6041	66R	46-9100	100P	54-5796-K	AA HVLP T
46-4004	3/8 inch	46-6018	66S	46-9300	93P	54-5797-K	AA HVLP F
46-4006	3/8F	46-6020	66SD	46-9400	94P	54-5798-K	AA HVLP T
46-3012	33PM	46-6092	66SD-3 (for Adhesives)	46-9503	95AP		
46-2352	352	46-6103	66SDJG (for Adhesives)	46-9502	95AS		

FLUID NOZZLES

PART NO.	FLUID NOZZLE	PART NO.	FLUID NOZZLE	PART NO.	FLUID NOZZLE	PART NO.	FLUID NOZZLE
45-9900	20T	45-6321	63BSS	45-9102	91F	45-9050	905
45-3321	33BSS	45-6331	63CSS	45-9200	92	45-9051	905VT
45-3301	33SS	45-6332	63CVT	45-9202	92F	45-9060	906
45-3601	36SS	45-6301	63SS	45-6860	92GS (Clear 1.2)	45-9090	909
45-3801	38SS	45-6402	64VT	45-9300	93	45-9091	909VT
45-9905	40T	45-6501	65SS	45-9400	94	45-1022	J2SS
45-4401	44SS	45-6601	66SS	45-9402	94F	45-1023	J3SS
45-4501	45SS	45-6608	66XSS (Extrusion .040)	45-6861	94GS (Clear 1.4)	45-84	J920SS - 460
45-4601	46SS	45-6701	67SS	45-9404	94S	45-85	J930SS - 460
45-4701	47SS	45-6702	67VT	45-9401	94VT	45-86	J940SS - 460
45-9908	55T	45-6801	68SS	45-9500	95	45-87	K960SS - 460
45-5701	57SS	45-6802	68VT	45-9600	96	45-6329	L3BSS (for Adhesives)
45-5911	59ASS	45-7801	78SS	45-6863	96GS (Clear 1.6)	45-6334	L3CSS (for Adhesives)
45-5912	59BSS	45-8900	89	45-9700	97	45-6605	L6SS (for Adhesives)
45-5913	59CSS	45-8902	89A	45-9702	97F		
45-6201	62SS (.020)	45-9000	90	45-9704	97S		
45-6301	63SS (.028)	45-9002	90F	45-9010	901VT		
45-6311	63ASS	45-9100	91	45-9030	903		